Connection for 485SD9TB

TDA
TDB
GND
GND
+12V

TX/RX-
TX/RX+

Device

RS485

RS232

FROM PC